

MENU OPTIONS

For more information refer to the Downloads section of our website.



General

www.BioTrackSoftware.com

- 1) User Mgt
 - New user: Add users.
 - All user: Modify or delete existing users.
 - Display style: Change user display mode.
- 2) User Role
 - User defined role: Create user profiles to access the menu.
- 3) Comm
 - Ethernet: Configure the parameters for connections by TCP/IP.
 - Serial comm: Configures connection parameters for RS232/485/USB.
 - PC connection: Specifies the number of the reader and the communication key.
 - Wireless network: List of the available wireless networks.
 - Wiegand setup: Configure the Wiegand parameters.
 - ADMS: Configure the parameters for ADMS Cloud Server.
- 4) System
 - Date time: Modify the device's date and time. Configure daylight-savings time.
 - Attendance: Sets parameters related to records from users.
 - Fingerprint: Sets parameters related to fingerprints.
 - Reset: Return all options to the manufacturer's default configuration.
 - USB upgrade: Sets firmware upgrades.
- 5) Personalize
 - User interface: Parameters on how to view data on the screen.
 - Voice: Sets the parameters of voice and volume.
 - Bell schedules: Configure bells for shift change announcements.
 - Punch state options: Sets parameters related to records.
 - Shortcut key mapping: Sets hotkeys for some functions.
- 6) Data Mgt
 - Delete data: Delete records, managers and images.
 - Backup data: Allows data backup device.
 - Restore data: Restore from backup.
- 7) Access Control
 - Access control options: Allows locks configuration and parameter, sensors and alarm.
 - Time schedule: Sets shift change for users.
 - Holidays: Adds vacation days or holidays.
 - Access groups: Create groups for access control.
 - Combined verification: Enables door opening by two or more users combined.
 - Anti-passback setup: Enable antipassback function.
 - Durruss options: Alarm settings for unlocking.
- 8) USB Manager
 - Download
 - Upload
 - Download options: Download / Upload users, records or images via USB memory.
- 9) Attendance Search
 - User ID: Change the parameters for downloading.
- 10) Print
 - Date field setup: View a report of the records made by employees.
 - Printer options :
- 11) Short Message
 - Public messages: Allows the selection of the information for printing.
 - Personal messages: Allows print settings.
 - Draft messages
 - Messages options
- 12) Work code
 - New work code: Create new work code.
 - All work codes: Existing labor codes.
 - Work code options: Configuration of work code options.
- 13) Autotest
 - Test All
 - Test LCD
 - Test Voice
 - Test Keyboard
 - Test Fingerprint Sensor
 - Test Clock RTC
- 14) System Info
 - Device Capacity: Device capacity
 - Device Info: View of the device information like serial number, MAC address, etc.
 - Firmware info: Firmware information.